



ONE-KEY™ TICK™ BLUETOOTH® TRACKING TAG

IMPORTANT SAFETY INSTRUCTIONS

AWARNING READ AND UNDERSTAND ALL INSTRUCTIONS. Failure to follow all instructions listed below, may result in electric shock, fire and/or serious personal injury.

1. **SAVE THESE INSTRUCTIONS** - THIS OPERATOR'S MANUAL CONTAINS IMPORTANT SAFETY AND OPERATING INSTRUCTIONS.
2. **THIS DEVICE IS DESIGNED TO BE POWERED BY (1) CR3032 BATTERY.** Do not attempt to use with any other voltage or power supply.
3. **CHEMICAL BURN HAZARD. KEEP BATTERIES AWAY FROM CHILDREN.**
4. **THIS DEVICE CONTAINS A LITHIUM BUTTON/ COIN CELL BATTERY. A NEW OR USED BATTERY CAN CAUSE SEVERE INTERNAL BURNS AND LEAD TO DEATH IN AS LITTLE AS 2 HOURS IF SWALLOWED OR ENTERS THE BODY.** Always secure the battery cover. If it does not close securely, stop using the device, remove the batteries, and keep it away from children. If you think batteries may have been swallowed or entered the body, seek immediate medical attention.
5. **PROPERLY DISPOSE OF USED BATTERIES IMMEDIATELY.**
6. **DO NOT INCINERATE OR DISMANTLE BATTERIES.**
7. **UNDER ABUSIVE CONDITIONS, LIQUID MAY BE EJECTED FROM THE BATTERY, AVOID CONTACT. IF CONTACT ACCIDENTALLY OCCURS, FLUSH WITH WATER. IF LIQUID CONTACTS EYES, ADDITIONALLY SEEK MEDICAL HELP.** Liquid ejected from the battery may cause irritation or burns.
8. **DO NOT DISPOSE OF DEVICE OR BATTERIES TOGETHER WITH HOUSEHOLD WASTE MATERIAL!** Appliance and batteries that have reached the end of their life must be collected separately and returned to an environmentally compatible recycling facility.



SYMBOLGY



Volts



Direct Current



Read operator's manual.



Regulatory Compliance Mark (RCM). Product meets applicable regulatory requirements.



Bluetooth

SPECIFICATIONS

Cat. No.	ONEBATM
Volts	3 VDC
Battery Type	CR3032
Battery Life	3 yr
Recommended Ambient Operating Temperature	-20°C to 60°C
Signal Range	≥ 90m (300')
Ingress Protection	IP68
Impact Protection	IK06

GENERAL USE AND CARE

Tracker Activation

1. To begin, scan the QR code on top of the Tracker with the camera app on an iOS or Android device. When successful, the device will provide guidance for installing the One-Key™ app.
2. Scanning the QR Code after the app is installed will launch the One-Key™ app and provide guidance through the activation process.
3. Upon activation an audible tone will be heard, indicating the Tracker is ready to use.

ONE-KEY™ App / Account Set Up

1. To download the ONE-KEY™ app, visit the App Store or Google Play from your smart device. Create a User Name and Password and log in to a ONE-KEY™ account.
2. Bluetooth and Location Services must be enabled on the mobile device.
3. Location Services must be enabled in the Settings section of the App.

Attachment

The tracker is designed to track tools and equipment using the ONE-KEY™ App. It will not prevent theft from happening. The tracker can be attached in a variety of orientations. Consider attaching the tracker to prevent tampering.



The tracker can be attached using the following options:

- #8 Pan Head Self Tapping Screw
- Glue or Epoxy
- 4mm (5/32") Diameter Rivet
- Double sided tape or hook and loop fastening
- Cable or zip tie
- Key ring

AWARNING Follow all warnings and instructions packaged with your product, as well as these label instructions. Failure to follow all warnings and instructions could result in shock, fire, and/or serious injury.

1. Determine the best area on the item to attach tracker with minimal risk to abrasion or wear.

Do not secure in such a way as to impede the safe use of the product.

Do not attach on or near the following:

- vents
- safety notifications
- hand holds
- areas exposed to sparks or heat
- moving parts
- guards
- switches or controls

Before using screws or rivets, ensure the space behind the placement is clear.

Clean the surface area of item thoroughly.

If using an adhesive, firmly place the tracker in the desired location, allowing time to adhere.

Before using screws or rivets, ensure the space behind the placement is clear. Mounting hole distance is 38mm (1-1/2").

Use only mild soap and a damp cloth to clean, since certain cleaning agents and solvents may damage QR code.

For troubleshooting, use ONE-KEY™ app., or visit us at <https://www.milwaukeetool.com.au/one-key/>

WARRANTY - AUSTRALIA and NEW ZEALAND

Please refer to Australian and New Zealand warranty supplied with tool. This warranty applies only to product sold by authorised dealers in Australia and New Zealand.

SERVICE - AUSTRALIA and NEW ZEALAND

MILWAUKEE® prides itself in producing a premium quality product that is Nothing But Heavy Duty™. Your satisfaction with our products is very important to us! If you encounter any problems with the operation of this tool, please contact your authorised **MILWAUKEE®** dealer.

For a list of **MILWAUKEE®** dealers, guarantee or service agents please contact **MILWAUKEE®** Customer Service or visit our website.

(Australia Toll Free Telephone Number 1300 645 928)

(New Zealand Toll Free Telephone Number 0800 645 928)

or visit milwaukeetool.com.au/milwaukeetool.co.nz.

Milwaukee Electric Tool Corporation

13135 West Lisbon Road, Brookfield, Wisconsin U.S.A. 53005

Milwaukee Tool (Australia)

26 - 40 Nina Link, Dandenong South,
Victoria, 3175, Australia

Milwaukee Tool (New Zealand)

274 Church Street, Penrose,
Auckland, 1061, New Zealand

DESIGNED BY MILWAUKEE ELECTRIC TOOL CORP.

PROFESSIONALLY MADE IN CHINA

PRINTED IN CHINA