



# USB RECHARGEABLE 1100L TWIST FOCUS FLASHLIGHT

Cat. no.: L4 TMLED

## IMPORTANT SAFETY INSTRUCTIONS

**WARNING** READ AND UNDERSTAND ALL INSTRUCTIONS. Failure to follow all instructions listed below, may result in electric shock, fire and/or serious personal injury.

- SAVE THESE INSTRUCTIONS - THIS MANUAL CONTAINS IMPORTANT SAFETY AND OPERATING INSTRUCTIONS FOR THE REDLITHIUM™ USB BATTERY AND USB RECHARGEABLE LIGHT.**
- USE AND CHARGE ONLY REDLITHIUM™ USB BATTERIES IN THIS USB RECHARGEABLE LIGHT. OTHER TYPES OF BATTERIES MAY CAUSE PERSONAL INJURY AND DAMAGE.**
- BEFORE USING THE BATTERY AND LIGHT, READ THE OPERATOR'S MANUAL AND ALL LABELS ON THE BATTERY AND LIGHT.**
- AVOID DANGEROUS ENVIRONMENTS.** Do not charge battery in rain, snow, damp or wet locations. Do not use battery or light in the presence of explosive atmospheres (gaseous fumes, dust or flammable materials) because sparks may be generated when inserting or removing battery, possibly causing fire.
- CHARGE IN A WELL VENTILATED AREA.** Keep them clear to allow proper ventilation. Do not allow smoking or open flames near a charging battery. Vented gases may explode.
- USE ONLY RECOMMENDED ATTACHMENTS.** Use of an attachment not recommended or sold by the light or battery manufacturer may result in a risk of fire, electric shock or personal injury.
- TO REDUCE THE RISK OF ELECTRIC SHOCK,** always unplug before cleaning or maintenance.
- DO NOT BURN OR INCINERATE BATTERY PACKS.** Battery may explode, causing personal injury or damage. Toxic fumes and materials are created when battery are burned.
- DO NOT CRUSH, DROP, OR DAMAGE battery.** Do not use a battery that has received a sharp blow, been dropped, run over, or damaged in any way (e.g., pierced with a nail, hit with a hammer, stepped on).
- DO NOT DISASSEMBLE.** Incorrect reassembly may result in the risk of electric shock, fire or exposure to battery chemicals. If it is damaged, take it to a MILWAUKEE® service facility.
- BATTERY CHEMICALS CAUSE SERIOUS BURNS.** Never allow contact with skin, eyes, or mouth. If a damaged battery leaks battery chemicals, use rubber or neoprene gloves to dispose of it. If skin is exposed to battery fluids, wash with soap and water and rinse with vinegar. If eyes are exposed to battery chemicals, immediately flush with water for 20 minutes and seek medical attention. Remove and dispose of contaminated clothing.
- DO NOT SHORT CIRCUIT.** A battery pack will short circuit if a metal object makes a connection between the positive and negative contacts on the battery pack. Do not place a battery pack near anything that may cause a short circuit, such as coins, keys or nails in your pocket. Do not allow fluids to flow into battery pack. Corrosive or conductive fluids, such as seawater, certain industrial chemicals, and products containing bleach, etc., can cause a short circuit. A short circuited battery pack may cause fire, personal injury, and product damage.
- STORE** in a cool, dry place. Do not store battery where temperatures may exceed 50°C (120°F) such as in direct sunlight, a vehicle or metal building during the summer.
- TO REDUCE THE RISK OF INJURY, CLOSE SUPERVISION IS NECESSARY** when an appliance is used near children.
- STORE LIGHT OUT OF REACH OF CHILDREN.** Warm lights can become hazardous in the hands of children.
- KNOW YOUR LIGHT.** Read this manual carefully to learn your light's applications and limitations as well as potential hazards associated with this type of light.
- MAINTAIN LABELS AND NAMEPLATES.** These carry important information. If unreadable or missing, contact a MILWAUKEE® service facility for a replacement.

READ AND SAVE ALL INSTRUCTIONS FOR FUTURE REFERENCE.

## ADDITIONAL BATTERY SAFETY RULES

**WARNING** To reduce the risk of fire, personal injury, and product damage due to a short circuit, never immerse your tool, battery pack or charger in fluid or allow a fluid to flow inside them. Corrosive or conductive fluids, such as seawater, certain industrial chemicals, and bleach or bleach-containing products, etc., can cause a short circuit.

**WARNING** Do not charge non-rechargeable batteries.

## SPECIFICATIONS

Cat. No. ....	L4 TMLED
Rated power.....	12.8W
USB Input Volts .....	5V DC
USB Input Amps .....	0.1 - 2.1 A
Output Volts.....	4V DC
Output Amps.....	2.1 A
<b>REDLITHIUM™ USB Batteries</b>	
Volts .....	4V DC
Operating Temperature	
Battery .....	4°C to 40°C (40°F to 104°F)
Light .....	-20°C to 60°C (-4°F to 140°F)
IP rating.....	IP67

## SYMBOLLOGY

 Volts	 Universal Serial Bus
 Amps	 Class III appliance
 Direct Current	 Regulatory Compliance mark (RCM). This product meets applicable regulatory requirements.
 Read Operator's Manual	 Do not stare at the operating light source.

## BATTERY

### Maintenance and Storage

Do not expose your battery or cordless tools to water or rain, or allow them to get wet. This could damage the tool and battery. Do not use oil or solvents to clean or lubricate your battery. The plastic casing will become brittle and crack, causing a risk of injury. Store batteries at room temperature away from moisture. Do not store in damp locations where corrosion of terminals may occur. As with other battery types, permanent capacity loss can result if the pack is stored for long periods of time at high temperatures (over 50°C (120°F)). MILWAUKEE® Li-Ion batteries maintain their charge during storage longer than other battery types. After about a year of storage, charge the battery as normal.

**WARNING** To reduce the risk of injury or explosion, never burn or incinerate a battery pack even if it is damaged, dead or completely discharged. When burned, toxic fumes and materials are created.

### Disposing of MILWAUKEE® Li-Ion Battery

MILWAUKEE® Li-Ion batteries are more environmentally friendly than some other types of power tool batteries. Always dispose of your battery according to federal, state and local regulations. Contact a recycling agency in your area for recycling locations. Even discharged batteries contain some energy. Before disposing, use electrical tape to cover the terminals to prevent the battery from shorting, which could cause a fire or explosion.

## LIGHT

**WARNING** Use and charge only REDLITHIUM™ USB batteries in this USB rechargeable light. Other types of batteries may cause personal injury and damage.

**WARNING** The light source of this luminaire is not replaceable; when the light source reaches its end of life the whole luminaire should be replaced.

## Inserting the Battery

- Twist the cap and remove.
- Line up the battery with the compartment and fully insert the battery.
- Replace the cap and twist to secure.

## Charging the Battery

- Plug your USB cable into a suitable power source such as a computer or car port. Charge rates may vary depending on the power source's maximum output.
- Twist aluminum USB cover to expose the micro USB port. Insert the micro USB plug into the micro USB port.
- The indicator light will display the charging status:
  - Red Pulsing: Charging, 0-49%
  - Yellow Pulsing: Charging, 50-99%
  - Green Solid: Charging 100%
  - Red/Green Flashing: Cold, Wet, Faulty or No Battery
  - Red Solid: Battery pack temperature is over temperature (too hot)

If the light indicator flashes red and green, check that the battery is fully seated into the bay. Remove the battery and reinsert. If the light continues to illuminate solid red, the battery may be extremely hot. Allow the battery to cool down then reinsert. If the problem persists, contact a MILWAUKEE® service facility.

The solid red light indicator will stay on whether the flashlight is on or off. Once the battery pack is within the acceptable range, normal charging will take place and the red light indicator will turn off. If the problem persists, contact a MILWAUKEE® service facility.

## Operation

**CAUTION** To reduce the risk of injury, do not stare at the operating light source.

To avoid damage/discoloration to surfaces due to high temperatures, do not set the light lens-down.

Press the power  button to turn the light on and off. Press and hold the power  button to cycle through the modes: High, Medium, and Low. Release the power  button when you have reached desired mode. **NOTE:** The light will default to the selected brightness setting the next time it is turned on. The indicator light will display the battery life:

Red Flashing: 0-3% remaining	Red Solid: 3-10% remaining
Yellow Solid: 11-49% remaining	Green Solid: 50-100% remaining

**WARNING** To reduce the risk of injury, always unplug the power source from the battery before performing any maintenance. The battery has no internal serviceable parts. Never disassemble the battery.

## Maintenance and Storage

Store your light with battery in a cool, dry place.

As a general practice, it is best to unplug battery chargers and remove batteries when not in use. No battery damage will occur, however, if the charger and battery are left plugged in.

**WARNING** To reduce the risk of injury and damage, never immerse your battery or charger in liquid or allow a liquid to flow inside them.

## General Cleaning Practice

Clean out dust and debris from charger vents and electrical contacts by blowing with compressed air. Use only mild soap and a damp cloth to clean the battery and charger, keeping away from all electrical contacts. Certain cleaning agents and solvents are harmful to plastics and other insulated parts. Some of these include gasoline, turpentine, lacquer thinner, paint thinner, chlorinated cleaning solvents, ammonia and household detergents containing ammonia. Never use flammable or combustible solvents around batteries, charger, or tools.

### **WARRANTY - AUSTRALIA and NEW ZEALAND**

Please refer to Australian and New Zealand warranty supplied with tool. This warranty applies only to product sold by authorised dealers in Australia and New Zealand.

### **SERVICE - AUSTRALIA and NEW ZEALAND**

*MILWAUKEE*<sup>®</sup> prides itself in producing a premium quality product that is Nothing But Heavy Duty™. Your satisfaction with our products is very important to us! If you encounter any problems with the operation of this tool, please contact your authorised *MILWAUKEE*<sup>®</sup> dealer.

For a list of *MILWAUKEE*<sup>®</sup> dealers, guarantee or service agents please contact *MILWAUKEE*<sup>®</sup> Customer Service or visit our website.  
(Australia Toll Free Telephone Number 1300 645 928)  
(New Zealand Toll Free Telephone Number 0800 645 928)  
or visit [milwaukeetool.com.au/milwaukeetool.co.nz](http://milwaukeetool.com.au/milwaukeetool.co.nz).

#### **Milwaukee Electric Tool Corporation**

13135 West Lisbon Road, Brookfield, Wisconsin U.S.A. 53005

#### **Milwaukee Tool (Australia)**

21 Kelleys Road, Rowville, VIC 3178  
Melbourne, Australia

#### **Milwaukee Tool (New Zealand)**

274 Church Street, Penrose,  
Auckland, 1061, New Zealand

DESIGNED BY MILWAUKEE ELECTRIC TOOL CORP.

PROFESSIONALLY MADE IN CHINA

PRINTED IN CHINA

All trade marks are owned by Techtronic Cordless GP unless otherwise stated.

© 2020 Milwaukee Electric Tool Corporation.